

PRE9220

Remote trigger delay timer

Wiring diagram page 1 of 1




Cleverly simple control of energy.



Mount in a surface or sunken pattress box of 25mm or larger. To switch from more than one position simply wire two or more units in parallel to achieve two way and intermediate switching, or use the trigger terminal with a slave switch.

Rear view of unit



Due to our policy of continuous improvement, we reserve the right to change specifications without notice. All information was correct at time of when this product file was produced - April 2020