



Mount the PRE5003e unit no lower than 1.5 Meters ideally mount at chest height. Position at least 300mm away from the side of the heater/radiator, mounting less than 300mm from the heater will result in the thermostat incorrectly reading the room temperature. Do not mount the unit close to any extraneous heat sources for example Fridges, Large TV's and any other electrical devices that emit high levels of heat. When using no volt or low voltage ensure the link between "Live" and "COM" is removed.

