

PRE9250

Push button timer

Wiring diagram page 1 of 1




Cleverly simple
control of energy.



Mount in a surface or sunken pattress box of 25mm or greater. If fitting to a metal back box ensure that top and bottom lugs are removed.

Rear view of unit



Due to our policy of continuous improvement, we reserve the right to change specifications without notice. All information was correct at time of when this product file was produced - September 2020