

PRE9500

Thermal drive valve

Wiring diagram page 1 of 1




Cleverly simple
control of energy.



Screw the unit onto the existing radiator valve body making sure the valve is seated correctly. Connect to an isolated controlled 230V Supply.

Rear view of a
5 series thermostat




Live, Neutral and Live Return

Mains
Supply



Switched
fused spur



Due to our policy of continuous improvement, we reserve the right to change specifications without notice.
All information was correct at time of when this product file was produced - April 2020