


# irus PRE2000STC SMART tank control



Cleverly simple  
control of energy.



**NOTE: All electrical work must be carried out by a qualified electrician and conform to relevant regulations in force at time of installation.**

The Irus SMART Tank arrives Pre-wired from the factory, so no electrical work is necessary inside the SMART Tank Control box (STC).


Connect the appropriate LOAD cables to the Upper and Lower elements.

Connect the two white supply mains cables to their appropriate isolator. Ensure the supply cables have suitable strain relief at each isolator.

Ensure all connections are correctly and securely terminated. Perform wiring installation tests required in conformance with regulations in force at time of installation.

**NOTE: do not power the STC unless the tank is completely filled with water.**

PRE2000LDS



Due to our policy of continuous improvement, we reserve the right to change specifications without notice. All information was correct at time of when this product file was produced - February 2023